


MEMO





SERVICE INFORMATION	16- 1	OIL SEAL REMOVAL/INSTALLATION	16- 4
TROUBLESHOOTING	16- 2	PRELOAD ADJUSTMENT	16-11
FINAL GEAR CASE REMOVAL	16- 3	FINAL GEAR CASE INSTALLATION	16-15
BACKLASH INSPECTION	16- 3		

SERVICE INFORMATION

GENERAL

The final drive gear assembly must be removed for:

- Backlash inspection
- Oil seal and O-ring replacement

Replace all oil seals and O-rings whenever the final drive gear assembly is disassembled.

SPECIFICATIONS

		STANDARD	SERVICE LIMIT
Final gear oil	capacity	140-160 cc (4.7-5.4 ozs)	————
	recommended oil	Hypoid-gear oil API, GL-5 Above 5°C/41°F SAE #90 Below 5°C/41°F SAE #80	————
Gear backlash		0.08-0.18 mm (0.003-0.007 in)	0.30 mm (0.012 in)
Gear assembly preload		9.0-11.5 kg-cm (7.8-10.0 in-lb)	————
Pinion gear preload		5-6 kg-cm (4.3-5.2 in-lb)	————

TORQUE VALUES

Final gear case cover 10 mm bolts:	35-45 N·m (3.5-4.5 kg-m, 25-33 ft-lb)
8 mm bolts:	23-28 N·m (2.3-2.8 kg-m, 17-20 ft-lb)
Final gear case nuts	35-45 N·m (3.5-4.5 kg-m, 25-33 ft-lb)
Rear shock absorbers	30-40 N·m (3.0-4.0 kg-m, 22-29 ft-lb)
Drain bolt	10-14 N·m (1.0-1.4 kg-m, 7-10 ft-lb)
Filler cap	10-14 N·m (1.0-1.4 kg-m, 7-10 ft-lb)
Pinion shaft nut	40-50 N·m (4.0-5.0 kg-m, 29-36 ft-lb)
Rear axle nut	80-100 N·m (8.0-10.0 kg-m, 58-72 ft-lb)
Axle pinch bolt	24-29 N·m (2.4-2.9 kg-m, 17-21 ft-lb)



TOOLS

Special		
Retainer wrench	07910-3710000	
Final gear case base A	07965-4630100	— Not available in U.S.A.
Retainer wrench B	07910-4630100	
Pinion gear dis/assembly tool	07935-MB00000	
Oil seal remover	07948-4630100	— Not available in U.S.A.
Dis/assembly tool A	07965-3710101	
Dis/assembly tool B	07965-4630300	— Not available in U.S.A.
Oil seal guide	07973-4630100	
O-ring guide	07973-4630200	
Preload inspection tool	07924-3710000	
Oil seal driver attachment	07946-6920100	— Not available in U.S.A. or 07945-3330100
Attachment	07946-9370100	
Common		
Driver	07749-0010000 or 07949-6110000	
Pilot 20 mm	07746-0040400	

TROUBLESHOOTING

Rear Wheel Will Not Rotate Freely

1. Rear brake dragging.
2. Damaged wheel bearing.
3. Damaged ring and pinion gear bearings.
4. Bent rear axle.
5. Bent swingarm.
6. Excessive final gear assembly preload.

Excessive Noise

1. Worn or scored ring gear shaft and driven flange.
2. Scored driven flange and wheel hub.
3. Worn or scored drive pinion and splines.
4. Worn pinion and ring gears.
5. Excessive backlash between pinion and ring gear.
6. Oil level too low.


Oil Leak

1. Clogged hub breather.
2. Oil level too high.
3. Seals damaged.




FINAL GEAR CASE REMOVAL

Place the motorcycle on its center stand.
Remove the rear wheel (Page 15-2).
Drain the final gear oil if disassembling the gear case.



BACKLASH INSPECTION


Remove the distance collar.



Remove the oil filler cap.
Set a horizontal type dial indicator on the ring gear, through the oil filler hole.
Place a preload inspection tool over the pinion spline. Secure it with the three final gear case attaching nuts inverted, finger tighten only.
Rotate the ring gear by hand until gear slack is taken up. Turn the ring gear back and forth to read back lash.

STANDARD: 0.08–0.18 mm (0.003–0.007 in)
SERVICE LIMIT: 0.30 mm (0.012 in)

DIAL INDICATOR





FINAL DRIVE


Remove the dial indicator. Turn the ring gear 120° and measure backlash. Repeat this procedure once more. Compare the difference of the three measurements.

DIFFERENCE OF MEASUREMENT

SERVICE LIMIT: 0.10 mm (0.004 in)

If backlash is excessive, check the final gear assembly preload (Page 16-13).

If preload is correct, the final driven gear case assembly needs replacement.



OIL SEAL REMOVAL/INSTALLATION

NOTE


Replace all final gear case oil seals and O-rings whenever the case is disassembled.

RING GEAR BEARING RETAINER

Remove the final gear case assembly from the motorcycle (Page 16-3).


Remove the distance collar.

Straighten the dust guard plate lock washer tabs and remove the dust guard plate.



Remove the ring gear bearing preload retainer with the retainer wrench.

Remove the O-ring.






Remove the dust and oil seals from the retainer with a press and special tools.

NOTE

Place the dis/assembly tool B with its deep bore facing down.



DIS/ASSEMBLY TOOL A (2 Pcs.)
07965-3710101

DIS/ASSEMBLY TOOL B
07965-4630300
(Not available in U.S.A.)

Coat both new seals outer edges with gear oil. Press the new seals into the ring gear bearing preload retainer.

NOTE


Place the dis/assembly tool B with its deep bore facing up.

Coat the new o-ring with gear oil and install it. Install the ring gear bearing retainer being careful not to fold or damage the oil seal lips.

NOTE

After installing the ring gear bearing preload retainer, do the following:

- Final gear assembly preload check (Page 16-13).
- Backlash inspection (Page 16-3).




DIS/ASSEMBLY TOOL A (2 Pcs.)
07965-3710101

DIS/ASSEMBLY TOOL B
07965-4630300
(Not available in U.S.A.)

GEAR CASE


Remove the final gear case assembly from the motorcycle (Page 16-3). Remove the distance collar.

Straighten the dust guard plate lock washer tabs and remove the dust guard plate.



DUST GUARD PLATE


Loosen the ring gear bearing preload retainer 5 notches with the retainer wrench. Remove the eight gear case bolts and lift the gear case cover from the final gear case.



Remove the ring gear assembly.

NOTE


Use care when removing the ring gear as the oil seal spring band is easily turned inside out.



Remove the oil seal from the gear case.

CAUTION


Be careful not to damage the case during seal removal.





Coat the new oil seal with gear oil.
Install the oil seal squarely into the case being careful not to damage the bearing race.

DRIVER
07749-0010000 OR 07949-6110000





OIL SEAL DRIVER ATTACHMENT
07946-6920100 OR 07945-3330100

Remove the old sealant from the gear case and cover surfaces.


NOTE

- Keep the gear case clean.
- Be careful not to damage the gear case and cover mating surfaces.

Clean the gear case and cover mating surfaces with an oil stone.



Apply a liquid sealant to the gear case and cover mating surfaces.






FINAL DRIVE

Coat the gear case oil seal lips with gear oil.
Install the ring gear assembly, being careful not to damage or fold the oil seal lips.

RING GEAR ASSEMBLY



OIL SEAL


Fill the ring gear bearing retainer oil and dust seals with multipurpose NLGI No. 2 grease (MoS2-additive).

NOTE

Use a lithium-based multipurpose grease with MoS2-additive from one of the following manufacturers:

- MOLYKOTE BR2-S by Dow Corning, U.S.A.
- MULTIPURPOSE M-2 by Mitsubishi Oil, Japan
- Other lubricants of equivalent quality

MULTIPURPOSE GREASE



Place the gear case cover onto the final gear case. Insert the gear case cover bolts, positioning the three bolts with the symbol "⤴" in the photo at the locations shown. Alternately tighten these bolts until the cover just touches the gear case. Tighten all eight bolts in a crisscross pattern.

TORQUE:

8 mm bolts: 23–28 N·m
(2.3–2.8 kg·m, 17–20 ft·lb)


10 mm bolts: 35–45 N·m
(3.5–4.5 kg·m, 25–33 ft·lb)

NOTE

After installing the gear case cover, do the following:

- Final gear assembly preload check (Page 16-13).
- Backlash inspection (Page 16-3).


10 mm BOLTS **8 mm BOLT**





PINION GEAR RETAINER

Remove the final gear case assembly from the motorcycle (Page 16-3).
Remove the distance collar.




Install the preload inspection tool onto the pinion shaft.
Remove the pinion shaft nut and washer.

NOTE


The nut can be removed without grinding off the staked areas.

Remove the inspection tool and pinion joint.
Remove the retainer setting plate.

PRELOAD INSPECTION TOOL
07924-3710000




SETTING PLATE



RETAINER WRENCH B
07910-4630100

Remove the pinion retainer with the pinion gear retainer wrench.



Remove the retainer O-rings and oil seal.




Coat the new O-rings with MULTIPURPOSE NLGI No. 2 grease (MoS2-additive) and install them onto the retainer.

Fill the new oil seal groove with MULTIPURPOSE NLGI No. 2 grease (MoS2-additive).

Install the oil seal into the retainer with the oil seal driver.


BEARING DRIVER HANDLE A
07749-0010000 OR 07949-6110000 MULTIPURPOSE GREASE



OIL SEAL DRIVER ATTACHMENT
07946-6920100 OR 07946-9370100

Set the O-ring guide into the gear case cutout.
Install the oil seal guide over the pinion shaft.

O-RING GUIDE 07973-4630200 OIL SEAL GUIDE 07973-4630100






Push the retainer into place with the retainer wrench until the oil seal guide is contacted.

CAUTION

- Be careful not to damage the o-rings.
- The retainer has extra fine threads, and it is very easy to crossthread, if you are not careful.

Remove the oil seal and O-ring guides when retainer B seats against the bearing outer.



O-RING GUIDE
07973-4630200

O-RING


RETAINER WRENCH B
07910-4630100

Thread the retainer into the case by hand. Turn the pinion shaft intermittently. Stop tightening the retainer when pinion shaft rotating resistance is felt. Do not overtighten the retainer.

NOTE

- If the retainer is overtightened, it will cause excessive preload.
- A high amount of drag is normal because of the O-rings.

Check the pinion gear preload (below).




PRELOAD ADJUSTMENT

PINION GEAR RETAINER

NOTE

Use this procedure whenever the pinion gear retainer is removed.

Remove the dust guard plate.
Remove the ring gear assembly (Page 16-5, 16-6).



RETAINER WRENCH
07910-3710000



FINAL DRIVE

PRELOAD INSPECTION TOOL
07924-3710000

Install the preload inspection tool onto the pinion gear shaft.

Wind the wire around the tool groove and attach a spring scale. Measure the preload force needed to turn the pinion shaft in the normal direction of rotation.

PRELOAD: Pinion gear
1,000-1,200 g (2.2-2.7 lb)
5.0-6.0 kg-cm (4.3-5.2 in-lb)


Rotate the pinion shaft 50-60 turns if measurements are not even.

NOTE

Force required to begin movement may exceed preload specifications.


Tighten the retainer to increase preload.

Loosen the retainer and pull up on the pinion shaft with the special tool, if preload is excessive.




PINION JOINT

PINION GEAR
DIS/ASSEMBLY TOOL
07935-MB00000



After adjustment, install the proper retainer lock tab. There are two types.

Install the ring gear assembly (Page 16-7, 16-8).
Check the final gear assembly preload (Page 16-13).



LOCK TABS



RING GEAR RETAINER

NOTE

Use this procedure whenever the ring gear bearing retainer is removed, or if final gear assembly preload is being checked.

Install the preload inspection tool onto the pinion gear shaft.

Wind the wire around the tool groove and attach a spring scale. Measure the preload force needed to turn the pinion shaft in the normal direction of rotation.

PRELOAD:

1,800–2,300 g (4–5 lb)


(9.0–11.5 kg-cm, 7.8–10.0 in-lb)

NOTE

Force required to begin pinion movement may exceed preload specifications.

Remove the dust guard plate, if adjustment is necessary.

PRELOAD INSPECTION TOOL
07924-3710000




PINION JOINT

RETAINER
WRENCH
07910-3710000

Tighten or loosen the ring gear retainer as required to obtain the correct preload.

Remove the preload inspection tool.






FINAL DRIVE

Apply multipurpose NLGI No. 2 grease (MoS2-additive) to the pinion shaft and inside of the pinion joint.


Install the pinion joint, washer and 16 mm nut.



Install the Preload Inspection Tool to hold the pinion shaft, and tighten the 16 mm nut.

TORQUE: 40–50 N·m (4.0–5.0 kg·m, 29–36 ft·lb)


Stake the 16 mm nut to a minimum depth of 1 mm (0.04 in) at the two locations. Be careful not to damage the pinion shaft threads.



Install the dust guard plate and bend the three lock tabs up.

Bend one of the bearing retainer lock tabs down.


Remove the final gear case from the base, and insert the distance collar.





FINAL GEAR CASE INSTALLATION

Install the rear wheel and the final gear case (Page 15-6).



Apply Multipurpose NLGI No. 2 grease (MoS₂-additive) to the drive shaft joint grease fitting.

QUANTITY: 90 g approx. (at disassembly)

Make sure the final drive gear case drain bolt is tight.

Remove the oil filler cap.

Add the recommended lubricant until it reaches the filler neck threads.


RECOMMENDED OIL:

Hypoid Gear Oil API, GL-5

Above 5°C/41°F: SAE #90

Below 5°C/41°F: SAE #80

OIL CAPACITY: 140–160 cc (4.7–5.4 oz)



GREASE
FITTING

OIL FILLER CAP