


WIRING DIAGRAMS

CB750K



SWITCH CONTINUITY

IGNITION SWITCH					STARTER SWITCH				ENGINE STOP SWITCH		TURN SIGNAL SWITCH					DIMMER SWITCH			HORN SWITCH		
BAT1	IG	TL1	TL2	P	BAT3	HL	BAT2	ST	BAT2	IG	W	R	L	P	PR	PL	HL	Lo	Hi	HO	E
OFF					FREE				OFF								Lo			FREE	
ON									RUN								(N)			PUSH	
P									OFF								Hi				

- Br Brown
- Bk Black
- W White
- LG Light Green
- R Red
- G Green
- Y Yellow
- B Blue
- Gr Grey
- LB Light Blue
- O Orange
- P Pink

0030Z-425-6700